

# P500 PUMP

P/N : CL-W0132

1.

04532D

Installation

## Limited Liability

These warranties replace all other warranties, expressed or implied including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Thermaltake disclaims all other warranties, expressed or implied including, without limitation, implied warranties of merchantability and fitness for a particular purpose. Some jurisdictions do not allow the exclusion of implied warranties so this limitation may not apply to you. All expressed and implied warranties are limited in duration to the limited warranty period. No warranties apply after that period, some jurisdiction do not allow limitation on how long an implied warranty lasts, so this limitation may not apply to you.

Limitations of liability, Thermaltake's responsibility under this, or any other warranty, implied or expressed, are limited to repair or replacement, as set forth above. These remedies are the sole and exclusive remedies for any breach of warranty. Thermaltake is not responsible for direct, special, incidental, or consequential damages resulting from any breach of warranty or under any other legal theory including, but not limited to, lost profits, downtime, goodwill, damage to or replacement of equipment and property, and any cost of recovering, reprogramming, or reproducing any program or data stored in or used with a system containing Thermaltake product. Some jurisdictions do not allow the exclusion or limitation of incidental or exclusions may not apply to you.

Extent of limited warranty, Thermaltake does not warrant that your product will be free from design defects or errors known as "ERRATA". Current characterized errata are available upon request. This limited warranty does not cover any costs relating to removal or replacement of any part that is soldered or otherwise affixed to your system's motherboard. This limited warranty does not cover damages due to external causes, including accidental, problems with electrical power, usage not in accordance with product instructions, misuse, neglect, alteration, repair, improper installation, or improper testing. Nor is Thermaltake held liable for any bodily damage that may result during the installation, maintenance, repair, or is otherwise associated with this product, Thermaltake is free from any legal actions that may result in death, pain and anguish, or any other form of personal damage that may occur by purchasing this product.

You, the buyer, agree to this warranty and its term set within its expressed and implied limited warranty. This limited warranty gives you specific legal rights, and you may also have other right that varies from jurisdiction to jurisdiction.

## A.Components check >>




P 500 pump with  
500L/h flow rate



-ID 6.4 mm(1/4) quick install connectors x 2  
-ID 9.5 mm(3/8) quick install connectors x 2



Screws and nuts for fastening  
the pump onto chassis




Velcro tape to attach the pump  
to places without screw holes

 **Thermaltake**  
COOL// YOUR LIFE

# P500 PUMP

P/N : CL-W0132

2.




- A. P500 pump(CL-W0132)
- B. CPU waterblock (CL-W0010)
- C. 12 cm radiator (CL-W0002)
- D. AquaBay M3-liquid tank(CL-W0031)
- E. iTube 9(CL-W0055)

**B. Select the suitable size of Quick Install Connectors to install the P500 pump >>**




Choose the size of Quick Install Connector(You may choose the ID 6.4 mm or 9.5mm Quick Install Connectors)




Install the Quick Install Connectors (ex. ID 9.5mm Quick Install Connectors) into the liquid inlet and outlet of the pump

**C. Instal P500 pump 、CPU waterblock(CL-W0010) 、 1 2 cm radiator (CL-W0002) and AquaBay M3- liquid tank(CL-W0031)to build the liquid cooling system >>**



Install the pump to the chassis With screws and nuts(E)

Recommendation A :If your chassis does not have the mounting holes ,please follow installation guides shown on the right



Or



Tear off the Velcro film and adhere it onto the bottom of the pump




Tear off the tape of another side to fix it onto the chassis.

**C-1 To install CPU waterblock(CL-W0010) C-2 To install 12 cm radiator(CL-W0002) C-3 To install AquaBy M3(CL-W0031)**




Replace the ID 6.4 mm Quick Install Connectors with ID 9.5 mm Quick Install Connectors

Recommendation B: Please follow the manual of CPU waterblock to install it on the motherboard



Replace the ID 6.4 mm Quick Install Connectors with ID 9.5 mm Quick Install Connectors

Recommendation C: Please follow the manual of 12 cm radiator to install it inside the chassis



Install the the ID 9.5 mm Quick Install Connector to the location shown on photo

Recommendation D: Please follow the manual of AquaBay M3 to install it inside the chassis



**Thermaltake**  
COOL ALL YOUR LIFE



# P500 PUMP


P/N : CL-W0132

3.


## D. How to install the UV tube to connect the liquid cooling system

**Recommendation E:** Please purchase the iTube 9 (CL-W0055) to install the liquid cooling system


### D-1 ▶




Take apart the nut of the Quick Install Connectors



Take the UV tube (about 40 cm) and insert the nut into the tube. Then tighten the nut into the threads.





Take apart the nut of the Quick Install Connectors




Insert the nut into UV tube from the outlet of pump and tighten the nut into the threads.


### D-2 ▶



Do the same action to connect the outlet of CPU waterblock and inlet of radiator (The length of UV tube is about 20cm)





Take apart the nut of the Quick Install Connectors




Take the UV tube from the outlet of the CPU waterblock. Insert the nut into the UV tube and tighten the nut into the threads.

### D-3 ▶




Do the same action to connect the outlet of radiator and inlet of tank (The length of UV tube is about 40cm)



### D-4 ▶




Take apart the nut of the Quick Install Connectors



Insert the nut into UV tube from the outlet of radiator and tighten the nut into the threads




Do the same action to connect the outlet of AquaBay M3 and inlet of pump (The length of UV tube is about 40cm)




Take apart the nut of the Quick Install Connectors

**Installation complete**




Insert the nut into the UV tube from the outlet of the AquaBay M3 and tighten the nut into the threads.



Plug the 3 pin power connector from CPU waterblock



Plug the 4 pin connector of pump into the power supply's 4 pin connector



Pull the AquaBay M3 and open the cover of the tank to fill the coolant up to the "high" mark of the level indicator.

## To refill the coolant

**Thermaltake**  
COOL ALL YOUR LIFE

www.thermaltake.com 2006.07

